

ECU Manual for:

Bosch MSE 3.0



To scan this ECU download HUD ECU Hacker

<https://netcult.ch/elmue/HUD ECU Hacker>

No responsibility is taken for the correctness of the information



Pin	Usage
1	Ignition Coil
2	GND
3	Fuel Pump Relay
4	MIL Lamp
5	12 Volt
6	IAT Sensor
7	IACV Stepper Phase B
8	IACV Stepper Phase C
9	IACV Stepper Phase A
10	Sensor 5 Volt Output
11	12 Volt from Ignition Switch
12	CKP Sensor B
13	CKP Sensor A
14	Fuel Injector
15	O2 Heater
16	EVAP Canister Purge Valve
17	RPM Output
18	EHT Sensor
19	MAP Sensor
20	TPS Sensor
21	Sensor GND
22	IACV Stepper Phase D
23	12 Volt
24	O2 Sensor
25	Main Relay
26	K-Line